✳ ineo
www.ineo-usa.com

MODEL: T2566/T2566-II

Rugged External Enclosure
USB 3.0 to SATA HDD Enclosure

Getting Started

Thank you for purchasing ineo T2566 / T2566-II 2.5" SATA to USB 3.0 Rugged External Hard Drive Enclosure.This quick install guide provides step-by-step installation instructions and other important information regarding your ineo product. For the latest ineo product information and news, please visit our website at http:/www.ineo-usa.com

Package Contents

T2566/T2566-II	SATA HDD to USB 3.0
USB3.0 Cable	Yes(Integrated on enclosure)
Screw Kit	Screws x 6、Screw Driver x 1
Guarantee Card	Yes
User Manual	Yes

System Requirements

Hardware
Pentium® II, 200 MHz equivalent or newer for IBM compatible PC
PowerPC G4, 350 MHz or newer for PowerPC-based Apple Computer
Core® or newer for Intel-based Apple Computer

Software
Windows 2000/Mac9.1/Linux for USB2.0
Windows XP / VISTA / 7 / 8 / 8.1 / 10 & Mac OS X v.10.2+ for USB3.0
Note: For highest performance and reliability, ineo recommends that you install the latest service pack (SP) and updates.

■ Updating Your Operating System

Windows
Go to the Start menu and select Windows updates. For more information regarding updating your system, visit http://windowsupdate.microsoft.com.
Macintosh
Go to the Apple menu and select Software Update. For more information regarding updating your system, visit http://www.apple.com/macosx.

■ Handling Precautions

Ineo products are precision instruments and must be handled with care during unpacking and installation. Drives may be damaged by rough handling, shock, or vibration. Be aware of the following precautions when unpacking your ineo external storage kit:

▶ Do not unpack the product until you are ready to install it.
▶ Do not drop or jolt the product.
▶ Do not move the external storage when it is powered up.

Hard Disk Drive Installation

1. Open the back cover.

2. Insert the 2.5 inch HDD/SDD.

3. Close and put the screws back.

4. Connect the USB cable to the computer.

Part No.:EMT2566IN-US